


Ethylene Absorber User Guide

Model 19011 Mini Blanket 10in x 10in / 25.4cm x 25.4cm

1. Remove blanket from the barrier bag packaging
2. Remove self-locking tie taped to the outside of the bag
3. Hang blanket from the fan guard, suspended in direct air flow. If cooler design allows, hang on the return air side. Use self-locking tie or metal hooks to secure in place, making sure there is some clearance between the blanket and the fan.
4. Use one blanket for each fan in the cooler



Note:

- It's essential for blankets to be in the main air flow for maximum absorption of ethylene.
- It's normal for blankets to get dirty on the outside, over time. As the absorbing beads filter ethylene, the filter material also traps dirt particles from the air.
- Air Repair™ beads are a bright purple color when fresh. Upon exposure to air, and as ethylene is oxidized, they turn brown starting from the surface and eventually penetrating to the core of the bead.
- Blankets should be replaced every 6 months for continued protection of your ethylene sensitive products